
Exhibit 6

Sample Data QA/QC Steps





Updated

## Convert, QC and Upload **CCTV Inspections to SQL** STEP 1 Clear the CCTV Inspection Upload Tool of all inspection data before converting a new Clear Tool set of Inspections. Clear Tool STEP 2 Bring Inspections into this conversion/qc tool. Choose your CCTV Software: Import and convert to SCREAM CUES Granite XP Standard PACP Exchange **Format IT Pipes** Non-Standard PACP Exchange WinCan **PipeLogix** Other PipeTech STEP 3 Map the values to SCREAM values Map Values QC Mapped Values STEP 4 Perform Quality Control **Quality Control** Quality Control Checks STEP 5 Review Converted data. Run reports or view/edit raw data. Optional Optional Reports Review STEP 6 Assure photos and videos listed in this database exist in your file system. Check Check Photos and Videos Photos and Videos STEP 7 Upload Inspections Upload Inspections to Step 3: Media Check Manage Uploads SCREAM SQL Master DB

## Confirm the photos exist

Close

